


Installing VXi Updater

1 Requirements



- Microsoft® Windows® Vista or later
- .NET 4.0 Framework installed

2 Installation

1. Download the Updater installation file.
2. Navigate to where you downloaded the file to and double-click it to launch the installer.
3. Once the installer opens, click “Next” to begin the installation.




4. Accept the License Agreement and the read/write privileges.




Continued on page 2

Continued from page 1


5. Confirm the installation folder location, then click on “Next” to continue.




6. Choose how often you would like the Updater to check for new versions, then click on “Next” to continue.



7. Click on “Install” to confirm and start the installation. VXi Updater will now install.



8. When the application has installed, click on “Finish” to exit the installer.



Continued on page 3

Continued from page 2

Setup Complete

VXi Updater is now installed on your computer. You can access it from the Task Bar Tray.

