

# BlueParrott B650-XT

## What is the pass code or PIN for pairing my headset?

If prompted when pairing your headset, the pass code or PIN is "0000"  
(four zeros)