

BlueParrott B350-XT

How do I reset my Bluetooth headset?

When you reset your Bluetooth headset, the list of devices that have been paired with it is cleared. Follow these steps to reset.

1. Turn on your headset.
2. Simultaneously press and hold the **Volume up** button and **Volume down** button until you hear two low tones.
3. Your headset has now been reset.

Your headset will automatically enter pairing mode after successfully resetting.

Note

When your headset has been reset, you will need to re-pair with your Bluetooth devices. Remember to delete the previous pairing before you re-pair.