

# BlueParrott B550-XT

## How do I turn Microphone Proximity Mode on/off?

### Prerequisites

- [BlueParrott Updater](#)

To turn Microphone Proximity Mode on/off in BlueParrott Updater, follow these steps.


1. In BlueParrott Updater, click **Configure**.
2. In Microphone Proximity Mode, select **On/Off**.
3. Click **Save**.

### Note

If you turn off Microphone Proximity Mode, it will reduce the standby time.

If you have a BlueParrott B550-XT headset and firmware v. 1.28 installed, you will need to recalibrate the headset before turning this feature on.

## Applicable products



BlueParrott B550-XT