


BlueParrott S650-XT

How do I control Active Noise Cancellation and HearThrough?

When you are not on a call, you can cycle between ANC/HearThrough/Off by pressing the **ANC/HearThrough** button.



When you are on a call, the following conditions apply.

- ANC will stay on during a call.
- HearThrough will turn off during a call, and then resume when the call is finished.

Note

ANC and HearThrough works both when using your headset in stereo and mono mode.

Applicable products



BlueParrott S650-XT



BlueParrott B650-XT