

## BlueParrott B350-XT

### How do I know when my headset is fully charged or needs to be charged?

The LED on your headset will be solid red when it is charging.

When it is fully charged, the LED will change to solid Blue.