

BlueParrott B350-XT

How will I know when my headset has a low battery?

When the battery is low the LED indicator flashes red and "Battery Low" is announced.



Applicable products

