


BlueParrott B250-XT

How will I know when my headset has a low battery?

When the battery is low the LED indicator flashes red and two short tones will be heard in the receiver after 60 seconds.

Applicable products



BlueParrott B250-XT